

## INSTALLATION INSTRUCTIONS

1: Hold your new skylight shade over your existing skylight to ensure the garnish (white plastic portion) is centered over the existing skylight.

2. Choose a screw pattern (shown on these instructions) that will allow you to mount your shade without having any screws from your new skylight shade come in contact with existing screws from your RV skylight.

3. Hold the skylight shade firmly in position, or have someone hold it for you, and pre-drill the holes in your Skylight Shade using the 1/8" drill bit. NOTE: the location of the holes is based on the screw pattern you chose in the previous step.

\*\*If the screws of your new skylight shade will come in contact with your existing inner skylight, you will also need to pre-drill the inner skylight to avoid cracking the plastic edges on it. \*\*

5. Insert screw through screw cap base. While continuing to hold the shade firmly in place, use a power drill or hand screwdriver with Phillips Head bit, to put the provided screws into place. NOTE: DO NOT over tighten the screws, this can break your skylight shade. Only tighten screws until the perimeter of your skylight touches the ceiling of your RV.

6. Snap the white plastic screw-caps over the heads of the screws by pressing them on evenly and firmly.

## WARNING

DO NOT operate shade until fully installed. Operation before being securely mounting to your RV can cause damage to the shade mechanism or plastic garnish.

## HARDWARE INCLUDED

- 8 x Phillips Head Screws
- 8 x White Plastic Screw Caps
- 1/8" drill bit

## TOOLS NEEDED

- Power drill or hand screwdriver with Phillips Head or
- Screwdriver with Phillips-Head

 Screw Pattern A

 Screw Pattern B